

***Kestrel*[®] Interface**

Communicator Software Instructions

Thank you for purchasing the Kestrel Interface and Communicator Software. This system will upload the stored data from your Kestrel Meter to a computer for long-term storage, in-depth analysis or detailed charting. This system works with any Kestrel 4000 series model.

Before Starting

What's in the Box:

- Interface Cradle - Kestrel Meter snaps into the cradle for optical communication.
- A Serial or USB Cable - plugs into the interface and your computer.
- CD-ROM - upload software and necessary system files for PC, as well as the drivers for the USB adapter (needed for USB version only).

What You'll Need:

- A PC with an available serial or USB port.
- Windows 3.1 or higher.
- A Kestrel 4000 series Meter

Installing the Software

- Insert the Kestrel Communicator disk. The program will automatically install. Follow the prompts on the screen.
- If you need to install the USB drivers, search the CD for the "USB Adapter" folder, and select the .exe file in your operating system's folder.
- Once installed, click on the "Kestrel Communicator" icon on your desktop.
- Click on the "Help" tab for full instructions on how to use the Kestrel Communicator software with your interface.

